



**SmartGen**  
ideas for power

## HMP300

POWER INTEGRATED PROTECTION MODULE

## USER MANUAL



**SMARTGEN (ZHENGZHOU) TECHNOLOGY CO., LTD.**



Chinese trademark

**SmartGen** English trademark

**SmartGen** — make your generator *smart*

**SmartGen Technology Co., Ltd.**

**No.28 Jinsuo Road**

**Zhengzhou**

**Henan Province**

**P. R. China**

**Tel:** 0086-371-67988888/67981888

0086-371-67991553/67992951

0086-371-67981000(overseas)

**Fax:** 0086-371-67992952

**Web:** [www.smartgen.com.cn](http://www.smartgen.com.cn)

[www.smartgen.cn](http://www.smartgen.cn)

**Email:** [sales@smartgen.cn](mailto:sales@smartgen.cn)

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder.

Applications for the copyright holder's written permission to reproduce any part of this publication should be addressed to Smartgen Technology at the address above.

Any reference to trademarked product names used within this publication is owned by their respective companies.


SmartGen Technology reserves the right to change the contents of this document without prior notice.

#### Software Version

Date	Version	Note
2017-09-22	1.0	Original release.

## CONTENTS

1	OVERVIEW .....	4
2	PERFORMANCE AND CHARACTERISTICS .....	4
3	SPECIFICATION OPERATION .....	5
4	OPERATION .....	6
5	SCREENS DISPLAY .....	6
5.1	POWER DATA DISPLAY .....	6
5.2	ALARM DISPLAY .....	7
5.3	MODULE INFORMATION DISPLAY .....	7
6	PROTECTION .....	8
6.1	WARNING .....	8
6.2	TRIP ALARM .....	9
7	WIRINGS CONNECTION .....	10
8	SCOPES AND DEFINITIONS OF PROGRAMMABLE PARAMETERS .....	12
8.1	CONTENTS AND SCOPES OF PARAMETERS .....	12
8.2	ENABLE DEFINITION OF PROGRAMMABLE OUTPUT PORTS 1~4 .....	16
9	PARAMETERS SETTING .....	18
10	TYPICAL APPLICATION .....	18
11	INSTALLATION .....	19



## 1 OVERVIEW

**HMP300** power Integrated protection module integrates digitization, intelligentization and network technology which are used for collecting generator-set data (voltage, current, power and frequency) and related action output for data errors to protect the device. It fit with LCD display, optional Chinese and English languages interface, and it is reliable and easy to use.

**HMP300** power integrated protection module adopts micro-processor technology with precision parameters measuring, fixed value adjustment, set value adjusting and etc. All parameters can be configured from front panel or through LINK interface via PC. It can be widely used in all types of marine/land electrical device with compact structure, advanced circuits, simple connections and high reliability.

## 2 PERFORMANCE AND CHARACTERISTICS

Main features are as follows:

- 132x64 LCD with backlight, selectable language interface (Chinese and English), push-button operation.
- Equipped with LINK communication port. Through LINK interface via PC, data and parameters of module can be monitored and adjusted.
- Equipped with CANBUS port and can communicate with J1939 generator-set.
- Protections for over/under voltage, over/under frequency, reverse power, over power and over current.
- With harmonic test function, and each phase voltage/current harmonic distortion rate can be tested.
- Suitable for 3-phase 4-wire, 3-phase 3-wire, single phase 2-wire, and 2-phase 3-wire systems with frequency 50/60Hz;
- Collects and shows 3-phase voltage, 3-phase current, frequency and power parameters.

### Generator

Line voltage (Uab, Ubc, and Uca)

Phase voltage (Ua, Ub, and Uc)

Frequency Hz

### Load

Current Ia, Ib, Ic A (unit)

Each phase and total active power P kW (unit)

Each phase and total reactive power Q kvar (unit)

Each phase and average power factor PF

- Parameter setting: parameters can be modified and stored in internal FLASH memory and cannot be lost even in case of power outage; most of them can be adjusted using front panel of the controller.
- Widely power supply range DC (8~35) V, suitable to different starting battery voltage environment.
- All parameters used digital adjustment, instead of conventional analog modulation with normal potentiometer, more reliability and stability.
- Relay is mounted on the 35mm guide rail.






### 3 SPECIFICATION OPERATION

#### Technical Parameters

Items	Contents
Operating Voltage	DC8.0V to DC35.0V, Continuous Power Supply.
Power Consumption	<3W (standby ≤2W)
Alternator Volt Input Range	
3Phase 4Wire	30V AC ~ 360 V AC (ph-N)
3Phase 3Wire	30V AC ~ 620 V AC (ph-ph)
Single Phase 2Wire	30V AC ~ 360 V AC (ph-N)
2Phase 3Wire	30V AC ~ 360 V AC (ph-N)
Alternator Frequency	50 Hz /60Hz
Programmable Relay Output 1	5 A AC250V volt free output
Programmable Relay Output 2	5 A AC250V volt free output
Programmable Relay Output 3	10A AC250V volt free output
Programmable Relay Output 4	10A DC250V volt free output
Overall Dimension	107.6mm x 89.7mm x 60.7mm
CT Secondary Current	5A rated
Working Conditions	Temperature: (-25~+70)°C; Humidity: (20~93)%RH
Storage Condition	Temperature: (-25~+70)°C
Insulating Intensity	Apply AC2.2kV voltage between high voltage terminal and low voltage terminal; The leakage current is not more than 3mA within 1min.
Net Weight	0.30kg

## 4 OPERATION

Key descriptions are as follows,

Icons	Function	Description
	Set/Confirm	Pressing this key will enter into password screen; In setting parameter status, press this key will shift cursor or confirm setting value.
	Up/Increase	Scrolls the screen up; Shift the cursor up or increase the set value in parameter setting menu.
	Down/Decrease	Scrolls the screen down; Shift the cursor down or decrease the set value in parameter setting menu.
Press both  and  simultaneously can reset alarms.		

## 5 SCREENS DISPLAY

### 5.1 POWER DATA DISPLAY

1 <sup>st</sup> Screen	Description
<b>UL-L 380V 380V 380 V</b>	Line voltage Uab, Ubc, Uca
<b>UL-N 220V 220V 220 V</b>	Phase voltage Ua, UB, UC
<b>I: 500A 500A 500 A</b>	Current, IA, IB, IC
<b>P: 276 kW Q : 200 kvar</b>	Active power, Reactive power
<b>PF 0.80 50.0Hz</b>	Average power factor, Frequency
2 <sup>nd</sup> Screen	Description
<b>P(kW) Q(kVar) S(kVA)</b>	Active power display、Reactive power display、Apparent power display
<b>A: 89.0 65.0 110.0</b>	A phase: active power, reactive power, apparent power
<b>B: 89.0 65.0 110.0</b>	B Phase: active power, reactive power, apparent power
<b>C: 89.0 65.0 110.0</b>	C Phase: active power, reactive power, apparent power
<b>PF 0.80 0.80 0.80</b>	A phase, B phase and C phase power factors
3 <sup>rd</sup> Screen	Description
<b>THDu(%) THDi(%)</b>	Voltage harmonic distortion rate, current harmonic distortion rate
<b>A: 0.5 0.3</b>	A phase: voltage harmonic distortion rate, current harmonic distortion rate
<b>B: 0.5 0.3</b>	B phase: voltage harmonic distortion rate, current harmonic distortion rate
<b>C: 0.5 0.3</b>	C phase: voltage harmonic distortion rate, current harmonic distortion rate
<b>Phase Seq 0° 120° 240°</b>	Phase sequence
4 <sup>th</sup> Screen	Description
<b>Total kWh</b> 276.3 kWh	Total active energy
<b>Total kvarh</b> 200.0 kvarh	Total reactive energy

## 5.2 ALARM DISPLAY

All alarm information (trip alarm and warning alarm) collected by the module is real-time displayed on the alarm screen as bellow,

Display	Description
Alarm Warning Alarm Under Volt Warning	Title
	Alarm type
	Alarm content

## 5.3 MODULE INFORMATION DISPLAY

Module information including output port status, software version, hardware version and release time can be displayed on this screen as bellow,

Display	Description
OUT: 1 2 3 4 ┆┆┆┆	Name of output port
	Outputs Status
Software Version: V1.3	Software version
Hardware Version: V2.1	Hardware version
Issue Date: 2017-09-20	Issue date

## 6 PROTECTION

### 6.1 WARNING

When controller detects the warning signals, alarm indicator flashes and LCD displays the warning information.

No.	Type	Description
1	Over Volt Warning	When the module detects that the generator-set voltage has exceeded the pre-set value, it will initiate a warning alarm and the corresponding alarm information will be displayed on LCD.
2	Under Volt Warning	When the module detects that the generator-set voltage has fallen below the pre-set value, it will initiate a warning alarm and the corresponding alarm information will be displayed on LCD.
3	Over Frequency Warning	When the module detects that the generator-set frequency has exceeded the pre-set value, it will initiate a warning alarm and the corresponding alarm information will be displayed on LCD.
4	Under Frequency Warning	When the module detects that the generator-set frequency has fallen below the pre-set value, it will initiate a warning alarm and the corresponding alarm information will be displayed on LCD.
5	Over Power Warning	When the module detects that the generator-set power (power is positive) has exceeded the pre-set value, it will initiate a warning alarm and the corresponding alarm information will be displayed on LCD.
6	Over Current Warning	When the module detects that the generator-set current has exceeded the pre-set value, it will initiate a warning alarm and the corresponding alarm information will be displayed on LCD.
7	Reverse Power Warning	When the module detects that the generator-set reverse power value (power is negative) has exceeded the pre-set value, it will initiate a warning alarm and the corresponding alarm information will be displayed on LCD.






## 6.2 TRIP ALARM

When controller detects trip alarm, it will send signals to trip the generator and the corresponding alarm information will be displayed on LCD.

No.	Type	Description
1	Over Voltage Trip	When the module detects that the generator-set voltage has exceeded the pre-set value, it will initiate a trip alarm and the corresponding alarm information will be displayed on LCD.
2	Under Voltage Trip	When the module detects that the generator-set voltage has fallen below the pre-set value, it will initiate a trip alarm and the corresponding alarm information will be displayed on LCD.
3	Over Frequency Trip	When the module detects that the generator-set frequency has exceeded the pre-set value, it will initiate a trip alarm and the corresponding alarm information will be displayed on LCD.
4	Under Frequency Trip	When the module detects that the generator-set frequency has fallen below the pre-set value, it will initiate a trip alarm and the corresponding alarm information will be displayed on LCD.
5	Over Power Trip	When the module detects that the generator-set power (power is positive) has exceeded the pre-set value, it will initiate a trip alarm and the corresponding alarm information will be displayed on LCD.
6	Over Current Trip	When the module detects that the generator-set current has exceeded the pre-set value, it will initiate a warning alarm and the corresponding alarm information will be displayed on LCD.
7	Reverse Power Trip	When the module detects that the generator-set reverse power value (power is negative) has exceeded the pre-set value, it will initiate a warning alarm and the corresponding alarm information will be displayed on LCD.
8	Loss of Phase Trip	When the module detects that generator-set voltage phase loss, it will initiate trip alarm signals and the corresponding alarm information will be displayed on LCD.
9	Phase Sequence Wrong Trip	When the module detects that generator-set voltage phase sequence wrong, it will initiate trip alarm signals and the corresponding alarm information will be displayed on LCD.

## 7 WIRINGS CONNECTION

HMP300 controller back panel is as follows:



HMP300 Panel

### Terminal Wiring Connection

No.	Function	Cable Size	Remarks
1	B-	1.5mm <sup>2</sup>	Connected with negative of starter battery, engine starter battery can be used directly.
2	B+	1.5mm <sup>2</sup>	Connected with positive of starter battery, engine starter battery can be used directly.
3	120Ω	1.0mm <sup>2</sup>	After short connecting with CANH, it is needn't external connect with 120Ω.
4	CANH	1.0mm <sup>2</sup>	CANBUS Communication port, which is support J1939-81 power data communication protocol.
5	CANL	1.0mm <sup>2</sup>	
6	Aux. Output 1	1.0mm <sup>2</sup>	Relay normally open volt free contact, rated 5A, and volt free contact output.
7		1.0mm <sup>2</sup>	
8	Aux. Output 2	1.0mm <sup>2</sup>	Relay normally open volt free contact, rated 5A, and volt free contact output.
9		1.0mm <sup>2</sup>	
10	Aux. Output 3	1.0mm <sup>2</sup>	Relay normally open volt free contact, rated 10A, and volt free contact output.
11		1.0mm <sup>2</sup>	
12		1.0mm <sup>2</sup>	
13	Aux. Output 4	1.0mm <sup>2</sup>	Relay normally open volt free contact, rated 10A, and volt
14		1.0mm <sup>2</sup>	

Details see **8.2**



No.	Function	Cable Size	Remarks
15		1.0mm <sup>2</sup>	free contact output.
16	Gen L1 Phase Volt Monitoring Input	1.0mm <sup>2</sup>	Connect with output U Phase of generator (2A fuse is recommended)
17	Gen L2 Phase Volt Monitoring Input	1.0mm <sup>2</sup>	Connect with output V Phase of generator (2A fuse is recommended)
18	Gen L3 Phase Volt Monitoring Input	1.0mm <sup>2</sup>	Connect with output W Phase of generator (2A fuse is recommended)
19	Gen N Wire Input	1.0mm <sup>2</sup>	Connect with output N Wire of generator
20	CT A-Phase Monitoring	2.5mm <sup>2</sup>	External connected current transformer secondary coil (5A).
21	Input	2.5mm <sup>2</sup>	
22	CT B-Phase Monitoring	2.5mm <sup>2</sup>	External connected current transformer secondary coil (5A).
23	Input	2.5mm <sup>2</sup>	
24	CT C-Phase Monitoring	2.5mm <sup>2</sup>	External connected current transformer secondary coil (5A).
25	Input	2.5mm <sup>2</sup>	
LINK			Test software interface. Connect with PC test software via SG72 module.

SmartGen

## 8 SCOPES AND DEFINITIONS OF PROGRAMMABLE PARAMETERS

### 8.1 CONTENTS AND SCOPES OF PARAMETERS

Parameters Settings and Scope (**FORM 1**)

No	Items	Range	Default	Description
<b>Voltage Settings</b>				
1	AC System	(0-3)s	0	0: 3P4W 1: 3P3W 2: 2P3W 3: 1P2W
2	Rated Voltage	(30-30000)V	230	Provide standard for over/under voltage and voltage on load. If voltage transformer is used, this value is primary voltage of transformer. When AC system is 3P3W, this setting value is line voltage; for other supply AC systems, it is phase voltage.
3	Voltage Transformer Enabled	(0-1) 0: Disabled 1: Enabled	0	Disabled
4	Primary Voltage	(30-30000)	100	Primary voltage of voltage transformer.
5	Secondary Voltage	(30-30000)	100	Secondary voltage of voltage transformer.
6	Over Volt Warning Enabled	(0-1) 0: Disabled 1: Enabled	1	When it is enabled, module starts to detect over voltage warning.
7	Over Volt Warning Value	(0-200)%	110%	When generator voltage has exceeded the setting value and warning delay is expired, module will initiate over voltage warning alarm.
8	Over Volt Warning Delay	(0-3600)s	3s	Time duration from alarm been detected to initiate alarm.
9	Over Volt Trip Enabled	(0-1) 0: Disabled 1: Enabled	1	When it is enabled, module starts to detect over voltage trip.
10	Over Volt Trip Value	(0-200)%	120%	When generator voltage has exceeded the setting value and trip delay is expired, module will initiate over voltage trip alarm.
11	Over Volt Trip Delay	(0-3600)s	2s	Time duration from alarm been detected to initiate alarm.
12	Under Volt Warning Enabled	(0-1) 0: Disabled 1: Enabled	1	When it is enabled, module starts to detect under voltage warning.
13	Under Volt Warning Value	(0-200)%	84%	When generator voltage has fallen below the setting value and warning delay is expired, module will initiate under voltage warning alarm.
14	Under Volt Warning	(0-3600)s	3s	Time duration from alarm been detected to



No	Items	Range	Default	Description
	Delay			initiate alarm.
15	Under Volt Trip Enabled	(0-1) 0: Disabled 1: Enabled	1	When it is enabled, module starts to detect under voltage trip.
16	Under Volt Trip Value	(0-200)%	80%	When generator voltage has fallen below the setting value and trip delay is expired, module will initiate under voltage trip alarm.
17	Under Volt Trip Delay	(0-3600)s	2s	Time duration from alarm been detected to initiate alarm.
18	Loss of Phase Detection Enabled	(0-1)	0	0: Disabled 1: Enabled
19	Phase Sequence Wrong Detection Enabled	(0-1)	0	
20	Under Volt Threshold Voltage	(0-200)%	60%	When threshold voltage is exceeded, module starts to detect under voltage trip.
<b>Frequency Settings</b>				
21	Rated Frequency	(50.0-60.0) Hz	50.0	Provide standard for over/under frequency and frequency on load.
22	Over Frequency Warning Enabled	(0-1) 0: Disabled 1: Enabled	1	When it is enabled, module starts to detect over frequency warning.
23	Over Frequency Warning Value	(0-200)%	110%	When generator frequency has exceeded the setting value and warning delay is expired, module will initiate over frequency warning alarm.
24	Over Frequency Warning Delay	(0-3600)s	3s	Time duration from alarm been detected to initiate alarm.
25	Over Frequency Trip Enabled	(0-1) 0: Disabled 1: Enabled	1	When it is enabled, module starts to detect over frequency trip.
26	Over Frequency Trip Value	(0-200)%	114%	When generator frequency has exceeded the setting value and warning delay is expired, module will initiate over frequency trip alarm.
27	Over Frequency Trip Delay	(0-3600)s	2s	Time duration from alarm been detected to initiate alarm.
28	Under Frequency Warning Enabled	(0-1) 0: Disabled 1: Enabled	1	When it is enabled, module starts to detect under frequency warning.
29	Under Frequency Warning Value	(0-200)%	84%	When generator frequency has fallen below the setting value and warning delay is expired, module will initiate under frequency warning alarm.
30	Under Frequency	(0-3600)s	3s	Time duration from alarm been detected to



No	Items	Range	Default	Description
	Warning Delay			initiate alarm.
31	Under Frequency Trip Enabled	(0-1) 0: Disabled 1: Enabled	1	When it is enabled, module starts to detect under frequency trip.
32	Under Frequency Trip Value	(0-200)%	80%	When generator frequency has fallen below the setting value and warning delay is expired, module will initiate under frequency trip alarm.
33	Under Frequency Trip Delay	(0-3600)s	2s	Time duration from alarm been detected to initiate alarm.
<b>Current Settings</b>				
34	Rated Full-load Current	(5-6000)A	500	It is generator's rated current, and used for provide standard for load current.
35	Current Transformer Ratio	(5-6000)/5	500	External connected current transformer ratio.
36	Over Current Warning Enabled	(0-1) 0: Disabled 1: Enabled	1	When it is enabled, module starts to detect over current warning.
37	Over Current Warning Value	(0-200)%	110%	When generator current has exceeded the setting value and warning delay is expired, module will initiate over current warning alarm.
38	Over Current Warning Delay	(0-3600)s	3s	Time duration from alarm been detected to initiate alarm.
39	Over Current Trip Enabled	(0-1) 0: Disabled 1: Enabled	1	When it is enabled, module starts to detect over current trip.
40	Over Current Trip Value	(0-200)%	114%	When generator current has exceeded the setting value and warning delay is expired, module will initiate over current trip alarm.
41	Over Current Trip Delay	(0-3600)s	2s	Time duration from alarm been detected to initiate alarm.
<b>Power Settings</b>				
42	Rated Power	(0-6000)kW	276	It is generator's rated power, and used for provide standard for power detection.
43	Over Power Warning Enabled	(0-1) 0: Disabled 1: Enabled	1	When it is enabled, module starts to detect over power warning.
44	Over Power Warning Value	(0-200)%	110%	When generator current has exceeded the setting value and warning delay is expired, module will initiate over power warning alarm.
45	Over Power Warning Delay	(0-3600)s	3s	Time duration from alarm been detected to initiate alarm.



No	Items	Range	Default	Description
46	Over Power Trip Enabled	(0-1) 0: Disabled 1: Enabled	1	When it is enabled, module starts to detect over power trip.
47	Over Power Trip Value	(0-200)%	114%	When generator current has exceeded the setting value and trip delay is expired, module will initiate over power trip alarm.
48	Over Power Trip Delay	(0-3600)s	2s	Time duration from alarm been detected to initiate alarm.
49	Reverse Power Warning Delay	(0-1) 0: Disabled 1: Enabled	1	When it is enabled, module starts to detect reverse power warning.
50	Reverse Power Warning Value	(0-200)%	20%	When reverse power value has exceeded the setting value and warning delay is expired, module will initiate reverse power warning alarm.
51	Reverse Power Warning Delay	(0-3600)s	3s	Time duration from alarm been detected to initiate alarm.
52	Reverse Power Trip Delay	(0-1) 0: Disabled 1: Enabled	1	When it is enabled, module starts to detect reverse power trip.
53	Reverse Power Trip Value	(0-100)%	30%	When reverse power value has exceeded the setting value and trip delay is expired, module will initiate reverse power trip alarm.
54	Reverse Power Trip Delay	(0-3600)s	2s	Time duration from alarm been detected to initiate alarm.
<b>Outputs Settings</b>				
55	Aux. Output 1 Setting	(0-30)	0	Default as not used
56	Aux. Output 1 Type	(0-1)	0	0: Normally open; 1: Normally close
57	Aux. Output 2 Setting	(0-30)	0	Default as not used
58	Aux. Output 2 Type	(0-1)	0	0: Normally open; 1: Normally close
59	Aux. Output 3 Setting	(0-30)	0	Default as not used
60	Aux. Output 3 Type	(0-1)	0	0: Normally open; 1: Normally close
61	Aux. Output 4 Setting	(0-30)	0	Default as not used
62	Aux. Output 4 Type	(0-1)	0	0: Normally open; 1: Normally close
<b>Module Settings</b>				
63	Module Address	(1-254)	1	Module address when remote monitoring control.
64	CANBUS Baud rate	(0-1) 0: 250Kbps 0: 125Kbps	0	CANBUS communication baud rate configuration.



No	Items	Range	Default	Description
65	Module Language Selection	(0-1)	0	0: Simplified Chinese; 1: English;
66	Module Password Setting	(0-9999)	00318	It is used to enter into parameter settings.

## 8.2 ENABLE DEFINITION OF PROGRAMMABLE OUTPUT PORTS 1~4

Programmable outputs 1-4 (**FORM 2**)

No.	Items	Description
0	Not Used	Output port is deactivated when "Not Used" is selected.
1	Common Alarm	Output when alarms occurred.
2	Common Warning Alarm	Output when warning alarms occurred.
3	Common Trip Alarm	Output when trip alarms occurred.
4	Over Volt Trip Alarm	Output when over voltage trip alarms occurred.
5	Under Volt Trip Alarm	Output when under voltage trip alarms occurred.
6	Loss of Phase Trip Alarm	Output when loss of phase trip alarms occurred.
7	Phase Sequence Wrong Trip Alarm	Output when phase sequence wrong trip alarm is occurred.
8	Over Frequency Trip Alarm	Output when over frequency trip alarm is occurred.
9	Under Frequency Trip Alarm	Output when under frequency trip alarm is occurred.
10	Over Current Trip Alarm	Output when over current trip alarm is occurred.
11	Reserved	Reserved
12	Over Power Trip Alarm	Output when generator over power trip alarm is occurred.
13	Reserved	Reserved
14	Reverse Power Trip Alarm	Output when generator reverse power trip alarm is occurred.
15	Over Volt Warning	Output when generator over voltage warning alarm is occurred.
16	Under Volt Warning	Output when generator under voltage warning alarm is occurred.
17	Reserved	Reserved
18	Reserved	Reserved
19	Over Frequency Warning	Output when generator over frequency warning alarm is occurred.
20	Under Frequency Warning	Output when generator under frequency warning alarm is occurred.
21	Reserved	Reserved
22	Over Current Warning	Output when generator over current warning alarm is occurred.
23	Reserved	Reserved
24	Over Power Warning	Output when generator over power warning alarm is occurred.
25	Reserved	Reserved
26	Reverse Power Warning	Output when generator reverse power warning alarm is occurred.





No.	Items	Description
27	Custom Output	Separately customized column A and column B output functions, when one is active, module will start output. Detailed to see <b>Form 3</b> as bellow.
28	Reserved	Reserved
29	Reserved	Reserved
30	Reserved	Reserved



Custom outputs form (**Form 3**)




No.	Custom Output Column A	Custom Output Column B
00	Over Volt Warning Alarm	Over Volt Warning Alarm
01	Under Volt Warning Alarm	Under Volt Warning Alarm
02	Over Frequency Warning Alarm	Over Frequency Warning Alarm
03	Under Frequency Warning Alarm	Under Frequency Warning Alarm
04	Over Power Warning	Over Power Warning
05	Over Current Warning	Over Current Warning
06	Reverse Power Warning	Reverse Power Warning
07	Phase Sequence Wrong Trip Alarm	Phase Sequence Wrong Trip Alarm
08	Over Volt Trip Alarm	Over Volt Trip Alarm
09	Under Volt Trip Alarm	Under Volt Trip Alarm
10	Over Frequency Trip Alarm	Over Frequency Trip Alarm
11	Under Frequency Trip Alarm	Under Frequency Trip Alarm
12	Over Power Trip Alarm	Over Power Trip Alarm
13	Over Current Trip Alarm	Over Current Trip Alarm
14	Reverse Power Trip Alarm	Reverse Power Trip Alarm
15	Loss of Phase Trip Alarm	Loss of Phase Trip Alarm

## 9 PARAMETERS SETTING

After module is power up, pressing  to enter into the password screen.

When entered password interface, inputting correct password (default password is "0318") to enter

into the parameter setting menu and select parameter item via pressing  and  buttons.

Then press  to start setting ( to increase value,  to decrease value). After the


setting is finished, press  again to confirm it.

Parameters also can be set through PC software via SG72 module after correctly entry the password (default password is "0318"). If there is need to set more parameters or the password is forgot, please contact the factory.

### NOTES:

- Over voltage set value must be higher than under voltage set value, otherwise over voltage and under voltage condition may occur simultaneously.
- Any alarms don't need, please select "Disabled" in the alarm enabled selection.


## 10 TYPICAL APPLICATION



HMP300 Typical Application

## 11 INSTALLATION

Overall and cutout dimensions:



### Attention:

#### a) OUTPUT AND EXPAND RELAYS

All outputs of controller are relay contact output type. If need to expand the relays, please add freewheel diode to both ends of expand relay's coils (when coils of relay has DC current) or, increase resistance-capacitance return circuit (when coils of relay has AC current), in order to prevent disturbance to controller or others equipment.

#### b) AC INPUT

Current input of controller must be connected to outside current transformer. And the current transformer's secondary side current must be 5A. At the same time, the phases of current transformer and input voltage must correct. Otherwise, the current of collecting and active power maybe not correct.

#### ▲NOTE:

When there is load current, transformer's secondary side prohibit open circuit.

#### c) WITHSTAND VOLTAGE TEST

When controller had been installed in control panel, if need the high voltage test, please disconnect controller's all terminal connections, in order to prevent high voltage into controller and damage it.